



# Samsung Galaxy A5 Display Replacement

This guide shows you how to replace the display of your Samsung Galaxy A5.

Written By: Tobias Isakeit



## INTRODUCTION

Use this guide to replace a broken or cracked display of your Samsung Galaxy A5.



### TOOLS:

- [iOpener](#) (1)
- [Suction Handle](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Spudger](#) (1)



### PARTS:

- [Galaxy A5 \(2015\) LCD Screen and Digitizer](#) (1)
- [Tesa 61395 Tape](#) (1)

## Step 1 — Display



- Switch off your phone.
  - ❗ If your screen is cracked you want to cover the front panel with tape to protect yourself from glass shards and get a better grip to lift it.
  - [Use an iOpener](#) to soften the glue on the edge of the display. Concentrate on the sides first and then on the bottom part.
  - With an iSclack or a suction handle you can lift the display a little bit to get in the gap with an opening pick.
- ⚠ In the beginning just insert the tip of the opening pick and slide along the side to loosen the glue. Leave the top and bottom alone for now.

## Step 2



- When the glue is loosened enough on the side you can lift the display a little bit more to get underneath the display with an opening pick.
- Take a second opening pick and work your way around the bottom edge.
- ⚠ Be careful where the two touch buttons are (see next step for orientation). Take your time and be patient.
- Repeat the last step and this one on the other side.

## Step 3



- Grab the [iOpener](#) once again to heat up the bottom and top part to further soften the glue.
- Now you will be able to move the picks at the bottom closer to the home button and eventually open the display towards the top.
- ⚠ Don't open the display all the way. It is still connected to the motherboard.
- ☑ The home button may stick to the display assembly or remain on the midframe. Keep an eye on it if your new display does not come with one already attached.

## Step 4



- In the top right corner you can find the connector of the display. Use a spudger to unplug it.
- Now you can remove the display.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-29 08:07:58 AM.